

OPERATING INSTRUCTIONS

Product: LYOTRAP - ULTRA
FREEZE DRYING MACHINE

Cat No: LF/LYO/04/1



FM 23948



0617

Issue level No.1

LYOTRAP

User Manual For Lyotrap Ultra Freeze-Drying Machine


Manual Ref. No:	UM0027	Issue No:	001
Machine Serial No:	Software Ref:
Pressure Vessel Ref:		
Description Of Any Options Fitted:			
.....			
.....			
.....			
.....			
.....			
.....			

Voltage:

Power:

Phase:

It would be most helpful if you could have the above information available when requesting technical advice or after sales service.



C H Perry
Chairman, LTE Scientific Ltd

Confidentiality

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, mechanical, photocopying, recording, or otherwise, without the prior written permission of LTE Scientific Limited. No patent liability is assumed with respect to the use of the information contained herein. While every precaution has been taken in the preparation of this manual, LTE Scientific Limited assumes no responsibility for errors or omissions. Neither is any liability assumed for damages resulting from the use of the information contained herein.

CONTENTS

	Page
1. Freeze Drying	6
2. Setting Up	6
3. Controls.....	7
4. Machine Operation for Freeze- Drying	8
5. General Maintenance	9

1. Freeze Drying

The products or items to be dried are placed in a drying chamber above the condenser chamber of the Lyotrap Ultra. The refrigeration is switched on to freeze the condenser chamber. Once the condenser chamber temperature is below -30°C the vacuum pump can be switched on (if set, the control panel will do this automatically).

As the vapour comes away from the products, it will be seen forming as frost on the sides of the condenser chamber.

When under vacuum, heat going into the products causes the ice to sublime, or vaporise. All the ice in the products will eventually boil off, without actually melting. The dried product should have retained its chemical composition.

2. Setting Up

To operate correctly, the machine needs to be level. The environment needs to be dust-free to avoid the refrigeration heat exchanger fins at the front of the machine from becoming clogged. The Lyotrap Ultra needs clear space around it to allow adequate air circulation.

The rubber door and top chamber lid seals must be kept clean to achieve a good vacuum and periodic wiping with white spirit is of advantage. Always allow spirit to evaporate before closing the chamber.

3. Controls

LED'S

Light up when the function is active.

Power

The power LED will light up when the machine is connected to a power supply using the power supply lead. The machine must be isolated from the power supply when the machine is not in use or when any maintenance work is undertaken.

Vacuum Pump

Switches on vacuum pump, but it will only operate if the condenser chamber temperature is below -30°C.

Refrigeration

Switches on the refrigeration system.

Defrost

This function will only work when the refrigeration system is switched off.

Vacuum Display

The display is in Millibars, or 1000ths of atmospheric pressure. When freeze drying it shows the level of vacuum in the system and this will vary throughout the drying cycle. This is because the products are giving off water vapour and gases that spoil the reading. Near the end of the cycle the pressure will be much lower. The display will read OFF while the vacuum pump is switched off. When the vacuum pump is switched on, the display will read ON. When the pressure has dropped to about 4 Millibars, or 4 x 1000ths of atmospheric pressure, it will then start to accurately register the pressure. When the Lyotrap Ultra is used for pump protection or for distillation the pressure will stay more or less constant.

Temperature Display

Shows the temperature in the chamber.


4. Machine Operation for Freeze-Drying

It is advisable to run through this procedure the first time with machine empty.

1. Connect the power supply to the power inlet side of the double socket with power supply cable.
2. Switch on the condenser chamber refrigeration. Place the products to be dried on the shelves above the condenser chamber in the acrylic chamber making sure the rubber seals and lid are in place. When flask drying, push the flask adapters into the rubber quick-seal valves of the manifold lid. Start the process with the valves closed, and open them one by one after a good vacuum achieved.
3. When the chamber temperature reaches -30°C, the vacuum pump can be switched on from the control panel.
4. If the vacuum display stays at ON, or if it does not drop below one Millibars then the system may be leaking. To find the leak you must switch off the vacuum pump, check all the seals, the door and the pressure release valve, and then try again.
5. At the end of the process, the refrigeration and vacuum pump can be switched off. Slowly turn the lever on the pressure release valve (situated on the front panel) to the open position to allow air back into the condenser and sample chambers. Defrost can be switched on to melt any ice remaining in the condenser chamber. The machine must be unplugged from the power supply when not in use.
6. The pressure release valve must be closed before the machine can be used again.

5. General Maintenance

- Oil mist and spillage around the vacuum pumps can occur and should be wiped clean as it attracts dust and dirt. If the surfaces around the pump are kept clean, abnormalities such as oil leaks are immediately apparent.
- The rubber seals should be kept clean; dirt is effectively removed with white spirit on a cloth.
- The refrigeration systems heat exchanger is at the front of the machine and is finned like a car radiator. This must be kept clean and away from anything that could restrict the airflow. The air must blow through to take the heat out of the refrigerant and cool the system. The fins should be blown out with compressed air occasionally to keep them clean.
- The oil level of the Vacuum pump must be checked regularly as oil will be used during the freeze-drying process. The level can be seen in the cutout to the lower left of the front panel.
- The vacuum pump oil must be changed at least every 6 months, as must the pumps internal filters.



DECLARATION OF CONFORMITY

PRODUCT	LYOTRAP ULTRA
CATALOGUE NUMBER
SERIAL NUMBER

***"We declare that the above CE marked product conforms
with the following EU Directives."***

**EMC Directive - 89/336/EEC as amended by Directive
92/31/EEC.
Low Voltage Directive - 73/23/EEC**

C H Perry, Chairman
LTE Scientific Ltd, Greenfield Lane, Greenfield, Oldham. OL3 7EN